How to Use ISOLUTE PLD+ Protein and Phospholipid Depletion Columns

ISOLUTE PLD+ columns provide extremely efficient removal of proteins and phospholipids from blood based samples using a simple 3 step procedure.

Recommended Operating Procedure

Before you start, ensure collection vessel is in position.

- 1. Dispense $300-400~\mu L$ crash solvent into each column. No dripping will occur.
- Dispense 100 μL sample (e.g. serum, plasma, whole blood) into each column. To ensure full protein precipitation and avoid cloudy extracts, it is important to achieve efficient mixing on sample addition. This can be achieved by:
 - a. Vortex mix: 30s-1min, or
 - b. Aspirate/dispense: 3-4 cycles, or
 - Dispense sample vertically into column, with force, and wait 5 minutes
- 3. Apply vacuum or positive pressure until sample is fully eluted (5 mins).

Recommended Crash Solvent

Acetonitrile or acetonitrile containing 1% (v/v) formic acid. Methanol or acidified methanol is also suitable.

See FAQ's (www.biotage.com) for further information on maximizing analyte recovery.

Mixing

If insufficient mixing occurs on sample addition, proteins will not precipitate efficiently. This can lead to turbidity (cloudiness) in extracts or blockage during processing.


Positive pressure processing:

Recommended pressure: 2 psi. When processing using Biotage® Extrahera™, set to 0.3–0.4 bar, for 6 minutes.

Vacuum processing:

Recommended vacuum: -0.1 to -0.15 bar

For maximum phospholipid removal, do not exceed these vacuum/pressure conditions. For very viscous samples, a slight increase in pressure or vacuum may be required. The use of high vacuum/pressure conditions may lead to breakthrough of matrix components.





Ordering Information

Part Number	Description	Quantity
918-0005-AG	ISOLUTE* PLD+ Protein and Phospholipid Removal Columns 50 mg/1 mL (tabless)	100
Accessories		
121-5202	Collection plate, 1 mL, square	50
121-5203	Collection plate, 2 mL, square	50
121-5213	Collection plate, 2 mL, round	50
121-5204	Piercable sealing cap	50
Vacuum processing		
121-9600	Biotage® VacMaster™-96 sample Processing manifold	1
121-9601	VacMaster VCU-1 Vacuum Control Unit	1
121-9602	VacMaster VCU-2 Vacuum Control and Generation Unit	1
Positive pressure processing		
PPM-96	Biotage® PRESSURE+ Positive Pressure Manifold, 96 position	1

EUROPE

Main Office: +46 18 565900 Toll Free: +800 18 565710 Fax: +46 18 591922 Order Tel: +46 18 565710 Order Fax: +46 18 565705 order@biotage.com Support Tel: +46 18 56 59 11 Support Fax: + 46 18 56 57 11

eu-1-pointsupport@biotage.com

NORTH & LATIN AMERICA

Main Office: +1 704 654 4900 Toll Free: +1 800 446 4752 Fax: +1 704 654 4917 Order Tel: +1 704 654 4900 Order Fax: +1 434 296 8217 ordermailbox@biotage.com Support Tel: +1 800 446 4752 Outside US: +1 704 654 4900 us-1-pointsupport@biotage.com

JAPAN

Tel: +81 3 5627 3123 Fax: +81 3 5627 3121 jp_order@biotage.com jp-1-pointsupport@biotage.com

CHINA

Tel: +86 21 2898 6655 Fax: +86 21 2898 6153 cn_order@biotage.com cn-1-pointsupport@biotage.com

To locate a distributor, please visit our website at www.biotage.com

